



Performance

This product is designed primarily to operate in summer months but will also work in spring and autumn provided there is good sunshine. Performance is directly related to the amount and strength of sunlight received.



Maintenance

To maintain optimum performance, regularly clean the solar panel using water or glass cleaner in conjunction with a non-abrasive sponge or cloth.



Thank you for purchasing this Smart Solar fountain.

Register your Product Here:

https://smartlivinghg.com/wp/customer-service/product-registration/

FAQs are available online along with step by step video tutorials to help you with pump cleaning and solar kit assembly.

Visit: https://smartlivinghg.com/wp/customer-service/faq/

PROBLEM	RESOLUTION (and page for reference)
The solar panel is in direct sunlight but the pump is not working.	 Ensure the connectors from the pump to the solar panel are secure - see pg 6 Ensure the pump is connected to the tube securely - see pg 2-3 Try Manual Pump Start - pg 7 (For Cascade) Ensure the tube is correctly attached to the jug
The pump is running but there is no water flow.	There may be an air bubble in the tube. 1. Try pouring water down the tube to force out the air bubble, then reattach to pump. 2. For Cascade: remove tube from top jug and submerge entire tube in main bowl. Once water is flowing out of the tubing, reattach to jug.
Cascade: Water is leaking from Jug	Check the tubing that attaches from the pump to the tube. Most likely the rubber bung is not tight enough in the hole that goes into the jug.

Smart Living Home & Garden warranties your solar panel, pump and battery (for Solar-on-Demand units) for one (1) year from the original date of purchase from authorized distributors and retailers. The warranty covers parts that are properly installed and regularly maintained. If the product fails due to a defect in material or workmanship, Smart Living will replace the defective parts free of charge. Your fountain is designed for outdoor use and with proper care will last for many years. If over time your fountain develops scratches or minor wear from normal use, you can contact our customer service department for easy to apply one step touch up paint.

Please unpack and inspect the entire product upon receipt. Report any broken or missing pieces within five (5) business days of receipt to our customer service department and we will provide replacement parts free of charge. Please do not discard any damaged parts until instructed to do so by our customer service department.



smart home & garden

Smart Solar is a Smart Living Home & Garden brand **Telephone:** + 1 813 343 5775 **Email:** customerservice@smartlivinghg.com **Web:** www.smartlivinghg.com